

"MAKE GOLF Practice FUN!"

# swing caddie

## SC200

### User Manual




- Distance Voice Output
- Loft angle selectable
- Instant feedback via LCD display
- Practice swing measurement.
- Distance adjustment by atmospheric pressure
- 3 Modes : Practice, Target, Approach.
- Daily and overall stats for each club
- Shot count and time display
- Simultaneous display

Carry Distance  
Swing Speed  
Ball Speed  
Smash Factor

## ► Package Contents

SC200 / Remote Control / User Manual

## ► Positioning



- Positioning Swing Caddie :  
1~1.5 meters (40~60 inches)  
directly behind the ball
- Range : 30~320 meters / yards

Remote Control


Mode selection

Club selection



- MODE : Select the desired mode in 3 modes (Practice > Target > Approach)
- STATS : Displays your average stats for each club (STATS > Club selection)
- SLEEP : Power saving mode (Saves energy and prolongs battery life during breaks) Press any button on the device or remote control to out of sleep mode
- Club selection : Press the button with club number

## ► Tip



## ► Basic Usage

Unit Selection: Press and hold the '\*' button on the Swing Caddie.  
YARD <--> METER , MPH <--> KM/H

\* Device only : unit selection is only available on the device, not remote control.

- Mode Selection : Press the M (Mode) button on the Swing Caddie or on the remote control.  
PRACTICE --> RANDOM --> TARGET

- Club Selection : Press the C (CLUB/STATS) button on the Swing Caddie or select your desired club on the remote control.  
( W1 > W3 > W4 > W5 > W6 > W7 > U3 > U4 > U5 > U6 > U7 > I3 > I4 > I5 > I6 > I7 > I8 > I9 > PW > AW > SW )

\* Select club directly using Remote control

## ► Practice Mode


Displays immediate feedback on the preceding shot.



## ► Target Mode

Before the shot: Displays your target distance.

After the shot: Displays your shot (carry) distance.



Use the + and - buttons to set your target distance.  
(range: 40~200 meters/yards) (increment: 5 meters/yards)

- In Target Mode, Swing Caddie scores each shot for accuracy.
- \* The pre-shot display shows your total score for the round. (perfect score: 100)
- \* The post-shot display shows your score for the preceding shot. (perfect score: 10)
- \* Tip: A bonus point (+1) will be awarded for matching the exact target distance!
- \* One round in Target Mode is 10 shots.

## ► Approach Mode

- Before the shot: Displays a randomly generated target distance. (range: 40~100 meters/yards)
- After the shot: Displays your shot (carry or total) distance.
- Use the + or - button to generate a new target distance.
- In Random Mode, Swing Caddie scores each shot for accuracy.
- \* The pre-shot display shows your total score for the round. (perfect score: 100)
- \* The post-shot display shows your score for the preceding shot. (perfect score: 10)
- \* Tip: A bonus point (+1) will be awarded for matching the exact target distance!
- \* One round in Random Mode is 10 shots.



## ► Stats

- Displays your average stats for each club. (shot distance, swing speed, ball speed, smash factor)
- Press and hold the C (CLUB/STATS) button or press the STATS button on the remote control to enter Stats Mode.
- Use the + or - button to switch between average stats for the last 100 shots (ALL) and average stats for the day (DAY).
- Press and hold the C (CLUB/STATS) button to reset stats.

### Display

Picture 1 : Accumulated average stats

Club(I4) avg. carry distance (182yards) avg. swing speed (85mph) avg. ball speed (118mph) Avg. smash factor 1.39 max carry distance (210 yards)

Picture 2 : Avg. in today

Club(I4) avg. carry distance (170 yards) avg. swing speed (80mph) avg. ball speed (104mph) Avg. smash factor 1.30 min carry distance (140 yards)

